

Fryer boil-out

VITO tabs - Spec Sheet



Fields of application:

Powerful, safe and easy cleaning of commercial deep fryers and stainless steel fryer accessories.

Product description:

- removes burnt-in grease and oil
- intensive cleaner packed as tabs for effective cleaning of commercial deep fryers
- individually packed, simple dose
- fryer accessories made of stainless steel can be cleaned as well
- easy to use, saves working time

Application:

Drain frying oil. Fill the deep fryer with water to the „Max“ mark (incl. stainless steel baskets and accessories) and add the VITO tabs according to the dose table. Heat the deep fryer to 80°C max. 90°C and let the solution boil for 15-20 minutes. Check the degree of cleaning, let it boil for longer if necessary. Drain solution and dispose it with a suitable container. Wipe off any remaining sediment with a sponge. Rinse the deep fryer thoroughly with water several times and dry.

Fryer capacity l / lbs	Number of VITO tabs
6-15 l	1
15-25 l	2

Ingredients:

<5%phosphonates, anionic surfactants, oxygen-based bleaches, sodium hydroxide, Disodium carbonate, Compound with hydrogen peroxide (2:3), Benzenesulfonic acid, C10-13 alkyl derivatives, sodium salt

Notice:

- not suitable for aluminium or other alkali-sensitive materials (e.g. household fryers)
- store in a cool and dry place
- use exclusively for the purpose for which it is intended
- keep locked up and out of the reach of children
- watch / check the label

Danger notice:

H290 may be corrosive to metals. H314 Causes severe skin burns and eye damage. P101 Requires medical advice. Keep packaging or label ready. P102 Keep out of the reach of children. P103 Read label before use. P260 Do not inhale dust. P280 Protective gloves/Wear protective clothing/eye protection/face protection. P301+P330+P331 IF HIDDEN: Rinse mouth, DO NOT induce vomiting. P303+P361+P353 IF IN CONTACT WITH SKIN(or hair): Remove all soiled, soaked garments immediately. Wash skin with water/shower. P305+P351+P338 IF IN EYE CONTACT: Rinse gently with water for a few minutes. Remove existing contact lenses if possible. Continue rinsing. P310 Call a POISON CENTER or doctor immediately. P501 Disposal of contents/container in accordance with the instructions given in the local / regional / national / international regulations.



Articles / Packaging

Item No.:	102995
EAN:	4000602005010
Weight tin	0,75 Kg (750 g)
1 box	15 tabs
1 carton	12 tins
Weight carton	9 Kg (9000 g)